



The machine must be configured with I/O function B, so that contact 6 is a START input, not a COIN input.
 If the machine is configured with a COIN input, use chart W1 instead.
 To start the machine, ACU sends a 24 V DC pulse.
 Feedback signal at line 18 shall remain active (high) during the entire program.
 User's payment is depleted when a feedback signal is received at IN1+, so feedback connection is mandatory.