



Connecting to ACU UI top terminals:  
 - max. wire cross section: 0.75mm<sup>2</sup>  
 - recommended: 20-23AWG solid conductors  
 - take out ACU power supply,  
 - insert wires into terminals,  
 - install power supply.

Disconnecting from top terminals:  
 - gently push the terminal down with  
 a small flat screwdriver,  
 - remove wire.

