



To open the barrier, ACU sends a pulse shorting terminals CO2 and NO2.
If a feedback signal from the barrier is available, use chart B1.