



- Auxiliary feedback contact must be connected between IN1+ and DC+ as shown, in order to deplete user's payment.
- ACU PCB jumper JP8 must be open. Scrape away the copper bridge in JP8 with a sharp awl as shown below. Do not scrape deeper or broader than needed, this can damage nearby lines.

